


## 10.2 Viewing counters (Meter Count)

The Meter Count screen can be displayed so that the total number of prints since counting started can be viewed.


In addition, the list of counters can be printed.

### To view the counters

- 1 Press the [Utility/Counter] key.
- 2 Touch [Details] in the sub display area.



The list of counters appears.



? Can the list of counters be printed?

→ To print the list of counters, touch [Print], select the paper size, and then press the [Start] key.

- 3 Touch [Close].

The Basic screen appears again.

