


10.2 Viewing counters (Meter count)

The Meter Count screen can be displayed so that the total number of prints since counting started can be viewed.


In addition, the list of counters can be printed.

To view the counters

- 1 Press the [Utility/Counter] key.
- 2 Touch [Details] in the sub display area.



The list of counters appears.



? How to print the list of counters?

- Touch [Print]. To print the list of counters, touch [Print], select the paper size, and then press the [Start] key.

- 3 Touch [Close].
The Basic screen appears again.

**Note**

The list of counters can be displayed even while the machine is copying or printing.

